

SORA /so-ra/ [noun]


The sky; open and boundless.
creating space by taking air away.

Meet SORA

Compact . Rechargeable . Effortless

Optimal Vacuum . -8 PSI


Help reduce air exposure and preserve freshness
Simply press and let SORA do the rest.



Before First Use

1. Charge SORA
Fully charge before first use.

Charging - Breathing white LED
Fully Charged - Solid white LED



2. Unlock SORA
SORA arrives locked in Travel Mode to prevent accidental activation during transit.

Press & hold the power button for 3 seconds



White LED blinks 3 times when SORA is unlocked



White LED blinks twice if SORA is still in Travel Mode.



To reactivate the Travel Mode Press and hold the Power Button for 3 seconds.

White LED blinks 3 times when Travel Mode is activated.

How to Vacuum

1 . Position
Place SORA over the vacuum valve



2 . Activate
Press once to start vacuuming

Solid Green LED



3 . Auto Stop
SORA automatically stops when it reaches -8 PSI



LED Indicator

Vacuuming	Green	Solid
Fully Charged	White	Solid
Charging	White	Breath
Low Battery	Amber	Blink
Locked	White	Blink
Lock/Unlock Confirmation	White	Blink

Care & Safety

Use SORA only when properly positioned over a compatible vacuum valve.
Do not operate the pump against a flat or sealed surface, as blocking the vacuum inlet may damage the motor.

Keep SORA dry.
Do not immerse in water or rinse under running water. Clean with a soft, damp cloth and keep the vacuum inlet clean and dry.

Charge with care.
Make sure the charging port is clean and dry before charging. Use a suitable USB-C power source.

Handle with care.
Keep SORA away from children, excessive heat and open flames. Do not use if the device or charging port is damaged.

Do not disassemble or modify SORA.
For product support or servicing, please contact C'EAL.

C'eal Story

SeaaMoment.

Designed for presence.
Engineered for effortless control.
Every detail is engineered to feel intuitive, balanced, and certain.

A simple act.
A quiet pause.
A moment sealed.

Designed in USA
Crafted for everyday performance

www.ceal.sg

Intertek